

TAPES AND EQUIPMENT FOR CORRUGATED BOARD

Reinforcing tape handling system

8×2 dispenser and M1800 feeding table: unwinding tapes from rolls and guiding them between the board layers. [1-3]



8×2 dispenser



M1800 feeding table

Equipment photographs from Lentprom materials

up to 8

tapes at once

8 + 8

working and spare rolls

manual

tape positioning

Two parts of one system

The dispenser holds the working and spare rolls and unwinds the tapes. The feeding table guides the tapes towards the line; insertion heads and guide rollers are mounted on a shared beam. [1]

A technical overview for discussing your application. Equipment scope, working dimensions and compatibility are agreed for your line.

01 / UNWINDING

8x2 dispenser

Unwinds reinforcing tapes from rolls. Each working position has a spare roll. [1,2]



Equipment photographs from Lentprom materials

Tapes at once

Up to 8

Roll arrangement

8 working + 8 spare

Spare roll provision

**One spare roll
per working position**

System pairing

M1800 feeding table

Two tape joining options

The source presentation describes two ways to join the ending tape to the new tape. The choice is agreed for the material in use. [1]

Cord

Described in the source presentation for thin liner paper.

Plastic clip

The second tape joining option described in the presentation.

For selection, provide the tape count, grade and dimensions, roll details and installation location. Speed and allowable loads require separate agreement.

02 / FEEDING AND POSITIONING

M1800 feeding table

Guides reinforcing tapes between the board layers. Tape positions are set manually. [1, 3]



Equipment photographs from Lentprom materials

Structure

One shared beam

Tape guidance

Insertion heads and rollers for up to 8 tapes

Positioning

Manual

Initial setting

Zero, usually at the centre of the corrugator

Beam length and installation

Beam length can be tailored to customer requirements. M1800 is a model designation; working dimensions and equipment placement are agreed during configuration. [1, 3]

Installation and support

Lentprom materials describe installation, assembly and training at the customer's premises. Routine maintenance and spare parts are available on separate request. The scope of work is agreed with the order. [1]

03 / INFORMATION FOR SELECTION

Configure for your line

Include the information you have with your technical enquiry. Leave unknown values blank and attach photographs of the installation area. These are inputs from your line, not equipment ratings.

Company and contact	Name, email or telephone <hr/>
Corrugator	Make / model; working width; line speed <hr/>
Reinforcing tape	Material / grade; width and thickness <hr/>
Tape positions	Number of tapes at once; required positions <hr/>
Roll details	Outside diameter; core diameter; width; mass <hr/>
Installation area	Available space; layout or photographs <hr/>
Joining and requirements	Cord / plastic clip; any additional requirements <hr/>

Discuss your configuration

info@lentprom.by | +375 29 140-44-41

Vitebsk, Belarus | Enquiry at lentprom.by/en/#request

Purpose: an overview for equipment selection. This is not a certified technical passport or a statement of operating limits. Final dimensions, compatibility, supply scope and service terms are agreed for the individual line.

Sources and edition

[1] Lentprom equipment presentation, pp. 1-3 (Russian).

[2] 8x2 dispenser page. [3] M1800 feeding table page.

Photos: Lentprom website materials. Edition: 30 October 2026.